



SET-O-MATIC

Since 1968

*The future in card technology
The future in coin meter technology*

291 Adams Boulevard
Farmingdale, NY 11735
Tel: 516-752-8008

1-800-645-3441

E-mail: info@setomatic.com
Website: www.setomatic.com
Fax: 516-752-8543

Wascomat "W" Series washers

\$15.75 Unit = 63 Coins To Start

Switch #'s	1	2	3	4	5	6	7*	8**
Coins to Start	1	2	4	8	16	32	Start	Off

Switch # 1 – 6 when in the ON position, represents Coins to Start

Examples: Switch # 2 On and # 4 On = 10 Coins to Start
Switch # 3 On and # 6 ON = 36 Coins to Start

IMPORTANT:

- * Dip-switch # 7 must always remain ON to give starting pulse
- ** Dip-switch # 8 must always remain OFF

When converting manual start machine to coin, remove wire on washer timer from post #3A and place to post #1B (This wire is marked #57A)